





## VERSITRIM CANTILEVER COPING


**DOUBLE CANTILEVER VERSION** 

## **STANDARD ACCESSORIES**




WALL SIZE + 10 <sup>3/8</sup>" = LENGTH





ENDWALL FLASHING COPING VERSION (RIGHT HAND SHOWN)



ENDWALL FLASHING SPLICE PLATE VERSION (RIGHT HAND SHOWN) (AVAILABLE ONLY IN .040" WELDED, PAINTED TO MATCH COPING)

## **NOTES**

Additional accessories are available including:

- Transition Miters
- Straight Transition Miters
- "T" Miters
- "Z" Miters
- Step-up Miters
- Peak / Valley Miters
- Pilaster Caps
- Radius Coping

For additional accessory requirements, attach sketches or call manufacturer for assistance.

	SHT #: of
Customer Service 800-558-2162	09/19/24
	DRN BY:JJC
	CKD BY:MM
	18011-23702 DWG #:
(Metal-Era)	c c